

LAVA Discover 132

USER MANUAL

General Information

Thank you for using our mobile phone Discover 132. This user guide provides general information and operation instructions.

Note:

- Use only accessories approved by the phone manufacturer to ensure safety. Failing to comply with this will violate the terms and conditions of the warranty.
- The phone set has been manufactured in strict compliance with various national standards and requirements set by the authorities. If the contents and displays described in this user guide do not match the actual operation of the phone set, please follow the contents and displays of your phone set. We reserve the rights to change any mechanisms of the phone without notice.

Step 4: After that enter the data settings as given on under Table1 on page 4-10 taking care of following:

Homepage: Check from detailed menu according to operator

Connection Type: Check from detailed menu according to operator

Proxy: Check from detailed menu according to operator

Port: Check from detailed menu according to operator

DNS: Primary DNS as mentioned in detail menu

In case NA or Null in detailed menu– No need to enter any data

EXAMPLE

Changing Settings for Airtel Live

Step 1: Menu→Settings→ Network & Connectivity →Cellular network settings→Data Accounts

Step 2: Select Airtel Live or in case Airtel Live doesn't exist Click Add

Step 3: Enter the details

Account Name: Airtel Live

APN: airtelfun.com

Username: Leave Blank

Username: Check from detailed menu according to operator

Password: Check from detailed menu according to operator

Authentication Type: Normal (in case of NA in detailed manual)

Advanced Settings: Edit required settings

Step 4: After that enter the data settings as given on under Table1 on page 4-10 taking care of following:

Homepage: Check from the row titled MMSC in table 1 according to operator

Connection Type: Check from detailed menu according to operator

Proxy: Check from detailed menu according to operator

Port: Check from detailed menu according to operator

DNS: Primary DNS as mentioned in detail menu

In case NA or Null in detailed menu– No need to enter any data

EXAMPLE

Changing Settings for Airtel MMS

Step 1: Menu→Settings→ Network & Connectivity →Cellular network settings→Data Accounts

Step 2: Select Airtel MMS or in case Airtel MMS doesn't exist Click Add

Step 3: Enter the details

Proxy address	172.017.083.069	172.017.083.069	000.000.000.000	100.001.201.172	100.001.201.172	000.000.000.000	010.004.042.015	010.004.042.015	000.000.000.000	010.239.21.005	010.239.21.005	NA
Proxy port	8080	8080		8799	8080	0	8080	8080	0	8080	8080	NA
Username	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Password	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Primary DNS	null	null	null	null	null	null	null	null	null	000.000.000.000	null	null
Secondary DNS	null	null	null	null	null	null	null	null	null	000.000.000.000	null	null
IP Address	null	null	null	null	null	null	null	null	null	000.000.000.000	null	null

[illegible]

IP Address	null	null	null	null	null	null	null	null	null	null	null	null	null
Subnet	null	null	null	null	null	null	null	null	null	null	null	null	null

Operator details	CELLONE-North	CELLONE-North	CELLONE-North	CELLONE-East	CELLONE-East	CELLONE-East	CELLONE-West	CELLONE-West	CELLONE-West	CELLONE-South	CELLONE-South	CELLONE-South
Profile name	BSNL MMS	BSNL LIVE	BSNL GPRS	BSNL MMS	BSNL LIVE	BSNL NET	BSNL MMS	BSNL LIVE	BSNL NET	BSNL LIVE	BSNL NET	BSNL MMS
Application type	MMS	BSNL LIVE	INTERNET	MMS	BSNL LIVE	INTERNET	MMS	BSNL LIVE	INTERNET	BSNL LIVE	Internet	MMS
APN	bsnlmms	bsnllive	bsnlnet	bsnlmms	bsnllive	bsnlnet	bsnlmms	bsnllive	bsnlnet	bsnllive	bsnlnet	bsnlmms
Authentication	None	None	None	None	None	None	NONE	NONE	NONE	NONE	NONE	NONE

[illegible]

APN	vgprs.com	vinter.net.com	vgprs.com	TATA.DOCOMO.DIV.IN	TATA.DOCOMO.MMS	TATA.DOCOMO.INTERNET	uninor	uninor	uninor	mizone	mizone	www
Authentication	NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE	PAP	PAP	PAP
User name	NA	NA	NA	NA	NA	NA	NA	NA	NA	91MDN	91MDN	91MDN
Password	NA	NA	NA	NA	NA	NA	NA	NA	NA	mmsc	mmsc	loop
Line Type	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Speed	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA
Homepage	http://10.202.4.119:10021/mmsc/	http://wap.google.com	http://wap.vlive.in	http://div.elin.tatadocomo.com	http://mmsc/	http://divin.tatadocomo.com	http://wap.muninoz.in	http://10.58.2.120	http://www.uninor.in	http://ms.loopmobile.in:8080	http://trafe.lopmobile.in	http://wap.google.com

Secondary DNS	null	null	Null	null	null	null	null	null	null	null	null	null
IP Address	null	null	Null	null	null	null	null	null	null	null	null	null
Subnet	null	null	null	null	null	null	null	null	null	null	null	null

All the configurations mentioned in this user manual is only for reference, please refer to the actual phone.

Your phone & Key parts



Label	Key	Description
1	Call Send Key	Make a call/ special function
2	Home Key	Return Home screen
3	Power Key/Back key	Press and hold to turn on/off phone Press to back previous screen
4	Camera	Camera shoot
5	3.5mm Earphone Jack	Earphone jack
6	Charging/USB port	Charging up/transfer files with PC.

Standby Screen & Icons



Alarm



Background playing / pausing



Memory card installed



Bluetooth on



Modem connecting

Comment [NJ1]: Symbol for
added

Airtel/ Airtel

Network carrier of Card 1/ Card 2

Text Input Method

This phone provides various text input methods that allow you to use less key strokes to input and search for text:

- English input method
- Hindi input method

- devices can affect the medical treatment and cause interference in aircraft.
- Some medical devices such as hearing aids and pacemaker may be sensitive to external radio frequency emissions. Consult the device manufacturers or your doctor before using the phone around the medical devices.
 - Pay special attention to the ring tone volume and vibration settings if you have a heart problem.
 - In areas with potentially explosive atmosphere, such as gas stations, fuel or chemical transfer or storage facilities, obey all signs and instructions.
 - Your phone will emit radio frequency even in the standby mode. Turn off your phone when so instructed.
 - Always obey all the local laws and regulations. Do not use your phone while driving. Use Hands-free operation, if available, and give full attention to driving and to the road. Pull off the road and park before making or answering a call if driving conditions so require.
 - If your phone is lost or stolen, notify your service provider immediately to stop the SIM card from being used.
 - When you contact your service provider, they will need your IMEI number. It is printed on the back of your phone set (you can find it when you remove your

- Do not paint the phone.
- Do not drop the phone or violently crush or shake the phone.
- Do not keep the phone near magcards and other object with magnetism. The phone's magnetism may clear the information stored on floppy disk, pre-paid phone card and credit card.
- Keep the phone away from hot places where the temperature may exceed 60°C, such as dashboard, windowsill, or areas exposed to direct sunlight.
- Do not disassemble or modify your phone. This can damage the phone, cause leakage and break the internal circuit.
- Use only damp cloth or non-static cloth to clean your phone.
- Do not use alcohol, thinner, benzene or other chemicals or abrasive cleaner to clean your phone.
- The phone will become warm under normal use and while in battery charging.
- Do not leave the phone with battery uninstalled or with the battery empty for a long period of time. This may cause data loss.
- The metal parts of the phone may irritate your skin depending on your health condition.
- Do not put the phone in the back pocket. Sitting on it may damage the phone.

- Keep metal objects (such as coins or key rings) away from the battery to avoid short circuit.
- Do not remove the battery without turning off the phone.
- Do not hold the battery in your mouth. The liquid of the battery can be toxic.
- Embedded battery shall be replaced by authorized dealers. Use only batteries approved by the phone manufacturer; otherwise, it may cause explosion.
- Damage resulting from using un-authorized batteries and chargers will not be covered by the warranty.
- Avoid contact with any leaked liquid of the battery. If it touches your skin, wash your skin with fresh water and go to the hospital immediately.

SAR

- The highest SAR value for this mobile phone is $< 1.6 \text{ W/Kg}$, in accordance with the requirements of the ICNIRP, which recommended the limit for exposure to radio waves is $1.6 \text{ watts/kilogram(W/kg)}$ averaged over 1 gram of tissue. For more information, please visit ([website](#)) to query

Safety precautions:

- Use cell phone when the signal quality is good
- People having active medical implants should preferably keep the cell phone

Comment [NJ2]: Add webs

- Collection Center.
- Separate the packaging material according to responsible waste disposal options and sorting for recycling.
- Always remove the battery from the product, when you do not intend to use the product anymore it in future.

Don'ts:

- Do not Dismantle your Lava Product on your own
- Do not give your e-waste to Kabbadi Wala / Scrap Dealer/ Rag Pickers.
- Do not dispose-off the e-waste in landfills
- Never dump E-waste in garbage bins.
- Do not dispose of your product at municipal waste bins or rooms.
- Do not throw used batteries into household waste.

Consequences of improper handling and disposal of E-Waste

- Improper disposal of waste prevents natural resources from being re-used.
- Some waste contains hazardous chemicals and if not disposed of properly may release toxins into the soil and water, and also releases greenhouse gases into the environment
- If e-waste is not properly disposed of, it can threat to the health and

Installing and uninstalling battery

To install the battery, remove the back cover from the phone by pressing firmly on the cover and slide it down. Align the golden contacts of the battery to the contacts in the phone, and then gently snap down the battery into place. Re-assemble the back cover.

To uninstall the battery, flip the battery out from the bottom of the battery.

Charging battery

Plug the charger into the socket on the side of your phone. Connect the charger to an AC wall socket. The blinking of the battery level icon indicates the battery is being charged. When the blinking stops, it indicates the charging is finished.

During charging, the phone and charger will feel warm to the touch. This is normal.

Warning:

The operating ambient temperature range of the charger is 0°C-50°C. Do not use the charger when the temperature exceeds this limit.

Use only chargers approved by the phone manufacturer to ensure safety. Failing to comply with this will violate the terms and conditions of the warranty.

Using battery

The waiting time and calling time capacities specified by the phone manufacturer

store on the SIM. You can take out the SIM card from the phone and insert it into another GSM phone to use it. Most new phones will recognize the SIM card automatically.

Do not touch the golden contacts of the SIM card; place it away from electricity and magnetism to avoid damage. You will not be able to use the phone if the SIM card is damaged.

Note:

- Before inserting and taking out the SIM card, always make sure that the phone is switched off and disconnected from any external power source; otherwise both the phone and the SIM card may be damaged.

Installing and uninstalling SIM Card

The SIM card usually comes attached to a special card. The metal contacts of SIM card can be easily damaged by scratching, so take it out carefully before assembling it into the phone.

Switch off the phone, remove the back cover, battery and other external power source. Fit the SIM card into the SIM card slot. Align the angled corner of the SIM card with the slot. Slide in the SIM card, make sure it is in place, install the battery, and restore the back cover.

cards, the two network carriers will both appear on the screen.

To make phone calls, you may dial the number from the Dial screen or from your phonebook.

Direct dial

Press the function key with respect to the dial icon on the Home screen.

Dialing from Contacts

Enter Phonebook from the Main Menu. You may use alphabet for quick search of the names.

Unanswered call

If you have set up Auto Re-dial, your phone will automatically re-dial the last unanswered number that you called.

Answering a call

When there is an incoming call, the phone will notify you through vibration, ringing, vibration plus ringing, etc, according to your setting. The name and phone number of the caller is shown on the screen if the network supports the service. You may answer or reject the call.

If call waiting is on when you are on the phone and there is another incoming call, your phone will notify you with a short tone. You may answer or reject that second

Create and delete a contact entry

1. On the dial screen, tap the Dialpad item, and then input the number and tap the Add contacts to create a new entry.
2. On the dial screen, tap the Contacts item, and then press the Call Send Key to create a new entry.

Note:

- On the Contacts item, press **Call Send Key** for more operation. Such as: Add contact, Groups, Share, Delete, Message, Settings.

Phonebook of SIM Card and your phone

There are two separate phonebooks, one stored on the SIM card and the other in the phone.

Each entry in your SIM card's phonebook consists of a phone number and a name. When you change to another phone, the contact information can be transferred to your new phone with the SIM card. The total number of entries allowed in a SIM card varies with different SIM cards.

The contacts stored in the phone can include name, phone number, group, photo, ring tone. This information will not be transferred with the SIM card to your new phone.

Message

This chapter introduces the messaging services provided by the network. Some services may not be supported by the local network

Write messages

SMS

Press  to enter the message screen, and then tap  or press Call Send Key to access the message editor screen. You may use virtual keypad or screen handwriting to input English, Hindi, digits and punctuation marks.

MMS

The MMS function allows you to send text and multimedia such as pictures, voice and video to the other phone. Additionally, you can send the MMS message using CC and BCC functions by pressing Call Send Key.

Note:

- On the message screen, Press Call Send Key for more operations. Such as: New msg., Delete, Settings, Backup SMS.
- On the message editor screen, Press Call Send Key for more operations. Such as: Send, Save, Insert, Add Subject, Cc/Bcc.

will be saved in AVI format to your memory card.

After entering the Camcorder function, the Camcorder Preview screen will appear with status icons. Tap  to start recording videos.

Recorded videos will be saved automatically. You can preview or delete them via the related operations

FM radio

Make sure the headset, which is used as the antenna, is plugged in before using the FM radio.

Play: Select it and then tap  to play it.

Record: Select and then play it, Tap  to record the channel.

Note:

➤ Before recording, make sure you have inserted a memory card.

The following functions are available by tapping  :

Auto search: Auto search channels.

Favorite: You can set up favorite channels. In Favorite menu, you have the following options: Add, Play, Edit, Delete, and Delete all.

Movie

Before using Movie, make sure you have inserted a memory card.

The Tools includes the following functions: Calendar, Alarm, and so on. Any others tools, you can download them by yourself.

Calendar

In addition to the western calendar, an India calendar is also provided. You can add, edit and look up events on different dates.

Alarm

You can set up to 6 alarm clocks. The Alarm Clock settings include: Title, Time, Status, Frequency and Ringtone. The frequency settings are: Once, Daily, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday and Sunday.

Alarm Dialog will be displayed when the alarm goes off. You can stop the alarm or snooze for 5 minutes.

Notes

You can Add new Notes, and also edit or remove the stored notes.

EBook

The eBook function lists the eBooks in TXT format stored in your memory card.

Calculator

A basic calculator is provided

World Clock

Facebook

You can login the facebook, this function is network dependent.

Face Talk

You can login the face talk, this function is network dependent.

Games

There are in-built games: Angry Bird, Fruit Ninja, Talk Cat. And also you can download from mSpace/[Game zone](#).

Settings

Enter Settings from the Main Menu. There are Network & connectivity, Personalization, System and Applications Settings.

Network & connectivity

Flight mode

You can set on/off.

Connectivity settings

Bluetooth

You may do functions for your Bluetooth settings such as: Turn on/off, Paired devices, Search devices, Settings.

Cellular network settings

Comment [NJ3]: Game Zone has many games like asphalt etc which are not available in the mSpace.

The default is 4321.

SIM lock: Allow you to check the SIM card lock status and change password.

System

Display settings

Brightness: Set the brightness of the backlight.

Screen auto-lock: You can lock your phone manually, or select auto lock for the phone to lock its screen automatically after some idle time in the Standby mode.

Date & Time settings

You can set the time, date, time zone, time format, date, date format and daylight saving time. Also you can turn on/off the auto-update network time.

Language & input

Set Display language & Smart input and Soft keyboard.

This phone provides several languages including English, Hindi and more.

Advance settings

SIM Usage: you can check the GPRS usage of the SIM card.

Restore factory settings: Restore your phone to the factory or default settings through this option. You need to input your phone password (default is 4321) for this operation. All data will be deleted when your phone is restored to its factory

User group: Turn on/off.

Contacts settings

You can set the storage, backup, restore, import, export feature for the contacts. Also you can set Speed dial list.

Messaging settings

Please refer to the Message chapter.

Extra Special Feature

Launcher

You can launch the launcher which you have set.

Lock

You can set the different lock screen style.

Home FX

You can set switching mode for the Home screen.

Downloads

You can look up downloading or completed apps, and also you can make the related operations.

Appendix

If you are in an area not covered by your network, or if a physical obstacle is present, such as in an enclosed area, the message "No service" will be displayed on your Standby screen and you will not be able to make or receive calls. You can try move closer to a window for better reception.

For emergency only

When you are outside your network but inside other network, you can only make emergency call.

No Valid SIM card

Your SIM card is locked or it has an error. Please insert the right SIM card or contact your service provider.

Enter PUK code

After three consecutive incorrect PIN code entries, the code is blocked, and you need the PUK code to unblock it. Contact your service provider to secure the 8-digit PUK code. After ten consecutive incorrect PUK code entries, the SIM card cannot be used any more. Please contact your service provider to buy a new SIM card

Care & Maintenance

Thank you for choosing our phone. Should you encounter any problem with the phone, please contact our dealer or qualified service provider.

- Do not drop, crush or shake the phone to avoid damaging the internal circuit board.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone.
- Do not paint the phone or the paint may obstruct the removable parts and affect operation.

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

The above instructions apply to your phone, battery, charger and other accessories. If any of them does not work properly, please send it to a qualified service provider.

Service center number

No: +919560394002

Kindly note please send area code of place through SMS to this No. and in return you will get address of service center nearest to you by SMS.